



BODYSTEEL & SILVER CO.,LTD

63 Moo 5, Soi Wat Bang-Co Yaek Rong-Foam, Kanchanaphisek Road
Bang Ma-Nang, Bang Yai, NONTHABURI 11140 THAILAND

☎ 66 2-1505999 📠 66-2-1505990

sales@steelsilver.com

EO STERILIZATION Quality Control Report

Date : 06-MAR-2024

LOT : 0930

STERILIZATION DATE : 22-FEB-2024

EXPIRE DATE : 22-FEB-2029

QC REPORT :

PASS as the test result has been shown as pictures below.

BIOLOGICAL INDICATORS :

The EZTest indicator is placed in a suitable test pack which is representative of the load. The load is then processed as usual.

After sterilization the chemical indicator ring on the label changes from blue to brownish when exposed to Ethylene Oxide (EO gas). This distinguishes exposed from unexposed units (it does not indicate acceptable sterilization).

After the incubation period of 48 hours, the appearance of a yellow color indicates bacterial growth. No color change indicates adequate sterilization.

Result
PASS



Sample Fail



Yellow

Sample New Indicator



Pink

Quality Assurance By:

Date: 06-MAR-2024



-STERI #45 C DAT 22/02/2024 10:49		930		FRESH (FRESH) (FRESH)	
STEP	TIME	TEMP (C)	TEMP (C)	TEMP (C)	TEMP (C)
PH	10:49	28.3	00	85.7	NONE
PV	12:20	45.0	00	87.6	NONE
HU	12:32	44.7	85	76.6	NONE
GS	12:42	44.7	84	60.5	NONE
ST	12:45	45.3	50	NONE	NONE
ST	13:15	44.6	49	NONE	NONE
ST	13:45	45.1	49	NONE	NONE
ST	14:15	45.2	49	NONE	NONE
ST	14:45	44.6	49	NONE	NONE
ST	15:15	45.2	48	NONE	NONE
ST	15:45	45.3	48	NONE	NONE
ST	16:15	44.6	48	NONE	NONE
ST	16:45	45.2	48	NONE	NONE
ST	17:15	45.5	48	NONE	NONE
AE	17:45	44.7	48	NONE	NONE
AE	18:45	45.3	48	NONE	NONE
-AE	18:52	00.0	52	NONE	NONE
FI	03:47	45.2	00	NONE	NONE

Protocol: